



ELBA- Residential Kitchen

Code	Product Description	Available
		QTY
98515602	COOKER HOOD ECH 602SS	4.00
98520090	COOKER HOODS H11-90 SS	15.00
98525060	COOKER HOOD F88-60SS	4.00
98525905	COOKER HOODS F88-905SS	3.00
98526060	COOKER HOOD F99-60SS / F99-605SS	2.00
98530001	COOKER HOOD CONCAVE	2.00
98530002	COOKER HOOD EDGE	1.00
98530006	COOKER HOOD STONE	3.00
98530008	COOKER HOOD GENIUS	4.00
98530009	COOKER HOOD ICELAND	1.00
98530010	COOKER HOOD DOLMEN	3.00
98530011	COOKER HOOD ICEBERG	3.00
98530012	COOKER HOOD STENAR	1.00
98531060	COOKER HOOD ELISUMMER 60CM	84.00
98531090	COOKER HOOD ELISUMMER 90CM	50.00
98550001	SPK1343 COOKER HOOD SPARE PARTS	6.00
98550002	SPK1296 COOKER HOOD SPARE PARTS	23.00
98550003	SPK1356 COOKER HOOD SPARE PARTS	2.00
98550004	SPK1331 COOKER HOOD SPARE PARTS N1	8.00
98550005	ACK62258 COOKER HOOD SPARE PARTS N1	20.00
98601060	CHIMNEY HOOD AQUA 60CM	10.00
99001009	FREE STANDING COOKER-VITROCERAMIC	2.00
99001106	FREE STANDING COOKER-SS FRAME	1.00
99001881	OVEN- FREE STANDING 9AS 881XL ELBA	4.00
99001882	ELBA COOKER 9 AS 881 XL	1.00
99001888	COOKER 90CM, SS, FULL GAS, 9AS 888X	4.00
99001889	ELBA COOKER 9 AS 888 XL	0.00
99001939	COOKER 90CM, SS, FULL ELEC,9AS 939X	0.00
99002031	HOB 74-030 SS	2.00
99002555	HOB-BUILD IN, 5 BURNERS 375.555X	13.00
99003510	BUILT IN GAS OVEN W/ GAS GRILL	1.00
99003621	OVEN 60CM. GAZ, 500 621 X	2.00
99003622	GAZ OVEN 500 622 X	1.00
99003860	GAS OVEN 108-60 X	15.00
99003960	BUILT-IN OVEN, 90CM, GAS, 109 60X	2.00
99004401	GAZ HOB 360 401 X	1.00

99004540	HOB 90CM. GAZ, ECONOMIC, 390 540 X	2.00
99004555	HOB 90CM, GAZ, HD, SS, 395-555X	2.00
99004645	HOB 90CM, GAZ 395 645 X	3.00
99005006	HOB 80CM, ELECTRIC, SS, CERAMIC EL58A0	14.00
99005007	HOB 80CM ELECTRIC SS CERAMIC	2.00
99006311	HOB 60CM, GAZ & ELECTRIC 360 311 X	1.00
99006312	GAS & ELECTRIC HOB EF60-310 X	5.00
99007510	GAS & ELECTRIC BIULT IN OVEN SS	16.00
99007610	ELECTRIC & GAS OVEN 610-100 X	3.00
99007721	OVEN 60CM. GAZ & ELECTRIC,500 721 X	61.00
99008100	OVEN 60CM,STAINLESS STEEL,ELECTRIC	1.00
99008101	OVEN 60CM,STAINLESS STEEL,ELECTRIC	2.00
99008102	BUILT IN ELECTRIC OVEN ROTISSERIE	3.00
99008160	ELECTRIC OVEN 101 60 X	1.00
99008260	ELECTRIC OVEN 102 60 X	2.00
99008600	ELECTRIC OVEN 210 600 X	1.00
99008606	OVEN 606-200 WH	1.00
99008620	OVEN 510-620 WH	1.00
99008721	OVEN 110-720 WH	2.00
99008722	OVEN 60CM, ELECTRIC 110 722 X	1.00
99008723	OVEN 110-722 WH	1.00
99008724	OVEN 110-724 WH	2.00
99008725	OVEN 110-725 WH	2.00
99010049	NOFROST FRIDGE/FREEZER, 660 LITERS	0.00
99011611	ELECTRIC FRYER AS E30-610 X	15.00
99013610	BUILT IN OVEN, LED ELECTRIC PROGRAM	1.00
99015050	BUILT IN HOB 2 VITROCERAMIC HI-	1.00
99015061	BUILT IN HOB FRONT CONTROL 4 RAPID	0.00
99021005	ELBA HOBS AS 345-005 SS	35.00
99021006	ELBA HOBS AS 377-006 SS	27.00
99021200	ELBA HOBS AS E30-200 X	1.00
99021301	HOB 271-301X	2.00
99021311	ELBA HOBS AS ES60-311 X	13.00
99021401	ELBA HOBS AS E60-401 X	1.00
99021410	ELBA HOBS AS-E90-410X	1.00
99021440	ELBA HOBS AS 246-440 X	17.00
99022070	ELBA OVEN AS 109-70 X	2.00
99022090	ELBA OVEN AS 108-90 X	2.00
99022800	ELBA OVEN AS 211-800 XN	5.00
99022801	ELBA OVEN AS 911-800 X	35.00
99023001	ELBA OVEN 91EX 880XT	8.00
99023002	ELBA OVEN 91EX 880XB	6.00
99025002	DISHWASHER EL99DW-BI	65.00
99040300	MICROWAVE 300-00SS	1.00
99040310	MICROWAVE 310-00 X	1.00
99050001	PAN SUPPORT - SPARE PARTS 217501	1.00
99050002	THERMOCOPLE - SPARE PARTS 107045	73.00

99050003	TR GAS TAP - SPARE PARTS 106254	30.00
99050004	SWITCH - SPARE PARTS 050039	72.00
99050005	ENERGY REGULATOR - SPARE PARTS	73.00
99050006	CUT-OFF THERMOSTAT - SPARE PARTS	67.00
99050007	BUTTON - SPARE PARTS 103271080	396.00
99050008	TRIPLE-RING BURNER HEAD-SPARE PARTS	31.00
99050009	BURNER CAP - SPARE PARTS 216133005A	17.00
99050010	BURNER CAP - SPARE PARTS 216132005A	34.00
99050011	OUTER BURNER CAP - SPARE PARTS	17.00
99050012	INNER BURNER CAP - SPARE PARTS	34.00
99050013	KNOB - SPARE PARTS 2183007373	33.00
99050014	RUBBER 040027	500.00
99050015	PAN-SUPPORTS/CAPS KIT-6309001	158.00
99050016	PAN-SUPPORTS/CAPS KIT-6309002	156.00
99051001	B058/651008215 HINGE SPRING ROD	3.00
99051002	B100/651008873 WATER SUPPLY HOSE	2.00
99051003	B120/651009012 WATER DRAIN HOSE	4.00
99051004	C070/651016532 HEATING ELEMENT	3.00
99051005	C163/651008591 UPPER IMPELLER DUCT	2.00
99051006	C198/651014189 TEMPERATURE SENSOR	5.00
99051007	C204/651014184 MICRO FOR SAFETY	5.00
99051008	C490/651016963 ELECTROVALVE	4.00
99051009	C270/651016184 ELECTRIC PUMP	4.00
99051010	C520/651008288 AIR BREAK	2.00
99051011	C650/651015829 MOTOR	1.00
99051012	A380/651016777 SWITCH	4.00
99051013	A420/651055408 SOAP DISPENSER AND	2.00
99051014	C520/651007771 AIR BREAK	1.00
99051015	C550/651000799 DOOR CLOSING CATCH	4.00
99051016	D020/651017149 BULBS	9.00
99051017	651017632 ELECTRIC MODULE	0.00
99052001	651014130 THERMAL PROTECTION	10.00
99052002	651003823 BULB COVER	10.00
99052003	651002922 THERMOSTAT KNOB	10.00
99052004	651050161 THERMOSTAT BOX	10.00
99052005	651018150 PTC THERMAL STARTER	10.00
99052006	651007215 DANFOSS ETF55 WIRE	4.00
99052007	651007886/651066293 ELECTRIC	1.00
99052008	651050382 REFRIGERATOR COMPRESSOR	4.00
99052009	651000561 RIGHT FIXED PIN HINGE	2.00
99052010	651066321 BUTTON GASKET	8.00
99052011	651000560 LEFT FIXED PIN HINGE	2.00
99052012	651004049 ON-OFF BUTTON	4.00
99052013	651066225 ON-OFF BUTTON	6.00
99052014	651051878 LED PCB	4.00
99052015	651002038 FRONT TRIM HANDLE	4.00
99052016	651066226 DISPLAY FUNCTION	12.00

99052017	651003845 COVER OF DRAWER HANDLE	2.00
99052018	651016186 ELECTRIC PUMP	3.00
99052019	651015831 MOTOR	2.00
99052020	651000355 LEFT FIXED PIN INNER DOOR	1.00
99052021	651000356 RIGHT FIXED PIN INNER	1.00
99052022	651016862 ANTIJAMMING FILTER	3.00
99052023	651008209 FILTERING CUP	2.00
99052024	651066308 AIR-BREAK SUPPORT RING	4.00
99052025	651013986 UPPER REVOLVING WHEEL	1.00
99052026	651013985 LOWER REVOLVING WHEEL	4.00
99052027	651051383/651053488 LED PCB	5.00
99052028	651050443/651016370 ON-OFF PUSH	5.00
99052029	651017237/651055408 SOAP DISPENSER	4.00